

# Fabrication of graphitic-carbon suspended nanowires through mechanoelectrospinning of photocrosslinkable polymers

A Osamu Katagiri Tanaka  
osamu.katagiri@exatec.tec.mx

Assessors:


Héctor Alán Aguirre Soto <alan.aguirre@tec.mx>

Dora Iliana Medina Medina <dora.medina@tec.mx>

30 Jan 2020



# Thesis Overview



Design polymer solutions that can be **electrospun** by NFES, **photopolymerized**, and then **pyrolyzed** into carbon nano-wires.




# Discover a new polymer solution to beat Braulio's record

Study solutions with high carbon polymers and no oxygen. No records


SU-8

+






V.S.


in THF




in THF & DMF



No records



in NMP



in Styrene



- FFES
- NFES

# The Carreau-Yasuda Model [1]

$$\frac{\eta - b}{a - b} = \frac{1}{[1 + (c\dot{\gamma})^e]^{\frac{1-d}{e}}}$$

$$\frac{\eta - \eta_{\infty}}{\eta_0 - \eta_{\infty}} = \frac{1}{[1 + (\kappa\dot{\gamma})^a]^{\frac{(1-n)}{a}}}$$

$$\eta = \frac{\eta_0 - \eta_{\infty}}{[1 + (\kappa\dot{\gamma})^a]^{\frac{(1-n)}{a}}} + \eta_{\infty}$$

where:

$\eta$  = Viscosity

$\dot{\gamma}$  = Shear rate


$\eta_{\infty}$  = Infinite shear rate viscosity

$\eta_0$  = Zero shear rate viscosity


$\kappa$  = Time constant

$n$  = The Power Law index


$a$  = The width of the transition region between the zero shear viscosity and the Power Law region




# PEO wt% in SU8




# PSMS wt% in DMF








# Standard Conforming to ASTM Oil Standard - Water Seal Test









# PS wt% in THF



# PSB wt% in NMP




# PSB wt% in THF and DMF




# Characterization of the 0.25 wt% PEO Solution

Electrospun-able with an applied voltage of 600V.




600V



Unable to initiate the jet at 500V or lower.

700V





INF-WIDR\_DEP

2 step(s)

Force Level 100%

Syringe

Custom, 1000 ul, 4.78 mm

Step: 1 Constant Rate

Rate: 100 ul/min

Target: 0.5 ul

Step: 2 Constant Rate

Rate: 100 ul/min

Target: 0.4 ul

Time Elapsed: 00:00:01

Total Volume Dispensed: 502.099 nl

Harvard Apparatus

Method complete, ready to start method.



HVS448 3000 V High Voltage Sequencer

ENABLE DISABLE



A

B

C

D

E

F

G


H

ALL

TRIGGER PAUSE



RUN STOP





HA Harvard Apparatus



Pump 11 Elite









# PEO Solution

The EMS polymer solution consisted of 2ml of **SU-8 2002** mixed with 0.5 wt% of **Poly(ethylene oxide)** (PEO, 4,000,000 MW; SigmaAldrich Inc., Cat. N. 189464) and 0.5 wt% **Tetrabutylammonium Tetrafluoroborate** salts (TBATFB; SigmaAldrich Inc., Cat. N. 217964) to increase its conductivity and allow smooth polymer flow during electrospinning.

All reagents were used as received. Magnetic stirring of these components was performed for 1hr at 75°C and low rpm (100-150 rpm).



# MICROCHEM CORP SU-8 2002 500ML

encompass

Manufacturer: MICROCHEM CORP Y111029

Catalog No. NC0702370

\$628.71 / Each

Qty  Check Availability

Add to cart

<https://www.fishersci.com/shop/products/NC0702370/nc0702370#?keyword=MICROCHEM+CORP+PHOTORESIST+SU-8>

# MICROCHEM CORP SU-8 DEVELOPER 4L

encompass


Catalog No. NC9901158

\$172.90 / Each


## INGREDIENTS:

Cyclopentanone (CAS: 120-92-3); 23-78%.  
Mixed Triarylsulfonium/ Hexafluoroantimonate Salt;  
(CAS: 89452-37-9)/(CAS: 71449-78-0); 1-5%  
Propylene Carbonate (CAS: 108-32-7); 1-5%  
Epoxy Resin (CAS: 28906-96-9); 25-75%


<https://www.fishersci.com/shop/products/NC9901158/nc9901158#?keyword=SU-8++developer>




Tetrabutylammonium tetrafluoroborate (TBF)




N,N Dimethylformamide (DMF)




Cyclopentanone (CAS: 120-92-3)



Mixed Triarylsulfonium/Hexafluoroantimonate Salt (CAS: 89452-37-9)/(CAS: 71449-78-0)



Propylene Carbonate (CAS: 108-32-7)



Epoxy Resin (CAS: 28906-96-9)  
2-(Chloromethyl)oxirane; formaldehyde; 4-[2-(4-hydroxyphenyl)propan-2-yl]phenol



# Zero shear viscosity measurements and Flores' measurements

Sample	PEO concentration [wt%]	Preliminary zero shear viscosity measurements [ <i>Pa.s</i> ]	Flores' zero shear viscosity measurements [ <i>Pa.s</i> ]
1	0.00	0.31	0.03
2	0.25	0.88	0.3
3	0.50	1.42	0.4
4	0.75	7.28	2
5	1.00	9.25	3

Both measurements have the same behaviour with similar proportions.

However, the results show that the current measured values are approximately three times larger than Flores' measurements.



<subTitle>

<content> <key concept>

